



## Useful tips on how to apply Noma<sup>®</sup> therm

- **Preparing the wall** - To prepare the wall surface would depend on what type of wall you have, if it is bare plaster then we would recommend that you size the wall first. Bare plaster can be porous and if not primed the adhesive used to apply Nomatherm could be absorbed into the wall and may cause it not to stick. Please ensure all surfaces are clean and **completely** dry before application. Do not apply to wet, damp walls.
- **Sticking to the wall** - To secure the Nomatherm to the wall we do supply our own adhesive called Decorfit alternatively a heavy duty, ready mixed wall paper paste will also be suitable - the kind you would use for heavy/embossed papers. Emphasis on the **heavy duty** as any normal paste will not be strong enough. If you decide to use another branded adhesive please ensure that it states '**suitable for PS veneer products**' and is non solvent. Please also note that it is the polystyrene side that is stuck to the wall.
- **Finishing the wall** - Finally Nomatherm can be finished with wallpaper; we **do not** advise that you paint Nomatherm.
- Please note that our company rejects all liability as a result of failure to follow the installation instructions